

---

2026 EDITION

# Technical Catalog HYPERDYNE

An integrated technology portfolio spanning high-power actuator hardware,  
control & algorithms, system applications, and evaluation & benchmarking infrastructure.

---

|                             |                                        |                        |                              |
|-----------------------------|----------------------------------------|------------------------|------------------------------|
| T 1                         | T 2                                    | T 3                    | T 4                          |
| Hardware<br>Core Technology | Control & Algorithm<br>Core Technology | System<br>Applications | Evaluation &<br>Benchmarking |

# Beyond Earth, operating in Space environments next-generation high-power intelligent work.


## ◆ MANIFESTO

### 'Physical Intelligence'

An ultra-precision physical-work platform powered by high-performance actuation technology.

From robotics to heavy industry and defense, all the way to space-scale heavy equipment.

Hyperdyne is pioneering Physical Intelligence.



BUSINESS SECTORS

# Where HYPERDYNE Drives

Five core business domains where Hyperdyne's proprietary actuation technology is applied.

01

## HEAVY INDUSTRY

Electric heavy equipment & construction robots



02

## ROBOTICS

Humanoid joints & autonomous mobile robots



03

## MOBILITY

Vehicle chassis · suspension · steering drive



04

## DEFENSE

High-power, high-precision defense systems



05

## SPACE

Extreme-environment & space-scale mission drives



CONTENTS

# Technology Index

14 technology items across four pillars — T1 Hardware, T2 Control & Algorithms, T3 System Applications, T4 Evaluation & Benchmarking.

|                                                          |                                          |    |        |                                            |    |
|----------------------------------------------------------|------------------------------------------|----|--------|--------------------------------------------|----|
| <b>T1 — Hardware Core Technology</b>                     |                                          |    |        | 4 ITEMS · p. 06–09                         |    |
| T1-A                                                     | QRHD — Quasi Rotary Hyper Drive          | 06 | T1-C   | RHD — Rotary Hyper Drive                   | 08 |
| T1-B                                                     | QLHD — Quasi Linear Hyper Drive          | 07 | T1-D   | LHD — Linear Hyper Drive                   | 09 |
| <hr/>                                                    |                                          |    |        |                                            |    |
| <b>T2 — Control &amp; Algorithm Core Technology</b>      |                                          |    |        | p. 10                                      |    |
| <hr/>                                                    |                                          |    |        |                                            |    |
| <b>T3 — System Applications</b>                          |                                          |    |        | 6 ITEMS · p. 12–17                         |    |
| T3-A-1                                                   | Four-Wheel Independent Active Suspension | 12 | T3-B-1 | Excavator Robot Platform                   | 15 |
| T3-A-2                                                   | Active Roll Stabilizer (ARS)             | 13 | T3-B-2 | Five-Bar Linkage 2-DOF Hopping Platform    | 16 |
| T3-A-3                                                   | Next-Generation Linear Active Strut      | 14 | T3-C   | Integrated Drive and Steering Wheel Module | 17 |
| <hr/>                                                    |                                          |    |        |                                            |    |
| <b>T4 — Evaluation &amp; Benchmarking Infrastructure</b> |                                          |    |        | 4 ITEMS · p. 19–22                         |    |
| T4-A                                                     | Dynamometer Test Infrastructure          | 19 | T4-C   | Quarter-Car HILS Tester                    | 21 |
| T4-B                                                     | Four-Stage Evaluation Protocol           | 20 | T4-D   | Robotic HILS Platform                      | 22 |

SECTION

# T1 Hardware Core Technology

4 ITEMS · DRIVE STACK

Built on four-axis design capability across motor, transmission, elastic element, and inverter — covering every drive requirement. A four-product lineup spanning Rotary/Linear × Quasi-Hyper/Hyper, scaling from collaborative-robot and humanoid joints to high-load industrial and vehicle applications.

Four - Actuator Lineup




|   |                                 |    |
|---|---------------------------------|----|
| A | QRHD — Quasi Rotary Hyper Drive | 06 |
| B | QLHD — Quasi Linear Hyper Drive | 07 |
| C | RHD — Rotary Hyper Drive        | 08 |
| D | LHD — Linear Hyper Drive        | 09 |



# T1 Hardware Core Technology

## 4 ELEMENTS · DRIVE STACK


HYPERDYNE leverages design expertise across motors, gearboxes, elastic elements, and inverters to address every actuation requirement and deliver the optimal solution.



# T1 Hardware Core Technology

4 ELEMENTS · DRIVE STACK

## Naming Convention



**Quasi-Hyper Series** — actuators optimized for high-load applications, with force-transmission efficiency of approximately 80%.

**Hyper Series** — actuators designed for high-load and high-efficiency operation, achieving force-transmission efficiency above 95%.

## Product Lineup

### Rotary

Quasi-Hyper Series



Required Tech  

Hyper Series



Required Tech   

### Linear



   Required Tech




    Required Tech

# T1-A Quasi Rotary Hyper Drive (QRHD)

HIGH-REDUCTION ROTARY ACTUATOR



Quasi Rotary Hyper Drive  
QRHD



## Overview

This rotary actuator achieves high efficiency and excellent backdrivability through the optimal design of a two-stage planetary reduction structure. By simultaneously optimizing the gear tooth numbers and profile shift coefficients, forward and reverse transmission efficiency are maximized, enabling higher efficiency and superior backdriving characteristics compared to harmonic drives of similar class. The actuator delivers medium-to-high torque within a compact volume and is packaged as an integrated unit with a BLDC motor, allowing direct application to collaborative robot and humanoid joints.

## Features

- Two-stage planetary reduction (Wolf from type) — medium-to-high reduction ratios and high torque within compact volume
- Quasi-Newton simultaneous optimization of tooth numbers and profile shift coefficients — maximizes forward and backdriving efficiency
- Minimized backdriving initiation torque — advantageous for contact-force detection and sensorless force estimation
- Integrated BLDC motor packaging — outer diameter and mounting pattern compatible with comparable harmonic drives

## Advantages

- Significantly improved forward-drive efficiency vs harmonic drives — reduced heat and power loss
- Minimized backdriving initiation torque — contact-force detection and force estimation without an additional torque sensor
- Maximized mechanical bandwidth — suitable for joints requiring fast position and force response
- Direct replacement within same external dimensions as comparable harmonic drives — no system redesign

## Applications



Collaborative robot & humanoid  
joint actuators



Human-robot interaction (HRI)  
systems

Systems requiring  
sensorless force estimation

High-efficiency industrial joints  
replacing harmonic reducers




# T1-B Quasi Linear Hyper Drive (QLHD)

HIGH-REDUCTION LINEAR ACTUATOR



Quasi Linear Hyper Drive  
QLHD



## Overview

This linear actuator features an optimized design that combines a high-lead ball screw with a single-stage planetary reduction mechanism. By leveraging the inherently high backdrivability and fast linear response characteristics of the high-lead ball screw, it is well suited for linear actuation applications requiring long stroke and high-speed response. When combined with current- and encoder-based sensorless force estimation, precise axial force control can be achieved without an additional force sensor. Its compact and lightweight integrated packaging also enables installation in space-constrained environments.

## Features

- High-lead ball screw + single-stage planetary reducer — fully electric design optimized for backdrivability, responsiveness, and compactness
- High backdrivability via high-lead ball screw — compliant linear motion characteristics that respond flexibly to external forces
- Serial configuration of BLDC motor, planetary reducer, and ball screw — compact, lightweight integrated packaging
- Current- and encoder-based sensorless thrust estimation — precise force control without an additional force sensor

## Advantages

- Excellent backdrivability via high-lead ball screw — high responsiveness to external forces and compliant linear motion
- Maximized mechanical bandwidth — suitable for high-speed linear position and force control
- Compact, lightweight packaging with single-stage planetary reducer — installable in space-constrained environments
- Sensorless force estimation enables precise axial force control without an additional force sensor

## Applications



Active strut




Industrial linear  
position-control actuators

Robot arms & legs  
linear joint actuators

Cooperative & wearable linear joints  
requiring backdrivability

# T1-C Rotary Hyper Drive (RHD)

ELASTIC-ELEMENT ROTARY ACTUATOR



## Overview

This rotary series elastic actuator (SEA) incorporates an elastic element in series with a high-reduction gearbox. The deformation of the elastic element is measured using an encoder to estimate absolute torque with a single sensor, enabling accurate torque sensing without additional hardware. High-fidelity impedance control is achieved through disturbance observer (DOB)-based active compensation of motor cogging and torque ripple. The inherent low-pass filtering characteristic of the elastic element absorbs external impacts, improving both actuator durability and operational safety.

## Features

- High-reduction gearbox with serially connected torsional elastic element — integrates high torque transmission and precise force measurement in SEA architecture
- TFSEA architecture: absolute torque measurement using a single encoder — minimizes sensor count and simplifies mechanical structure
- DOB-based active compensation of cogging and torque ripple — high-fidelity torque control
- Elastic deformation — based variable impedance spectrum with verified bidirectional linearity

## Advantages

- TFSEA architecture: absolute torque measurement using a single encoder — simplifies structure and wiring
- High-fidelity impedance control via DOB-based ripple compensation — precise force interaction
- Maximized mechanical bandwidth — suitable for joints requiring fast position and force response
- Flexible torque-density and compliance design through combination of elastic stiffness and reduction ratio

## Applications



**E-corner module**  
rotary suspension



**Legged robots**

Systems requiring  
**high-fidelity joint torque control**

Systems requiring  
**precise human interaction**


Systems requiring  
**low-impedance high-torque control**

# T1-D Linear Hyper Drive (LHD)

ELASTIC-ELEMENT LINEAR ACTUATOR



Linear Hyper Drive  
LHD



## Overview

This high-load linear series elastic actuator (SEA) incorporates an elastic element in series with a low-lead ball screw. The motor, ball screw, planetary reducer, and elastic element are serially integrated within a single strut structure, enabling precise axial force control through encoder-based measurement of elastic deformation without disturbance-sensitive force sensing. The elastic element both absorbs external impacts and provides force information, allowing reliable linear force control without an additional force sensor.

## Features

- Low-lead ball screw with serially integrated elastic element (F-SEA) — integrates high thrust transmission and precise force sensing in SEA architecture
- F-SEA architecture: serial motor – screw – nut – elastic element – rod configuration — integrated impact absorption and axial force measurement
- Encoder-based measurement of elastic deformation — disturbance-robust precise force sensing without an additional force sensor

## Advantages

- F-SEA architecture with encoder-based measurement of elastic deformation — disturbance-robust precise force sensing and control
- Integrated elastic element absorbs external impacts — protects ball screw and gearbox, improves durability and operational safety
- High thrust capability via low-lead ball screw — optimized for high-load linear actuation applications

## Applications



Humanoid lower body  
requiring high thrust



Rack-and-pinion systems  
requiring force control

Active struts requiring  
high-precision force control

# T2 Control & Algorithm Core Technology

2 SERIES · 6 CHALLENGES · CONTROL STACK

HYPERDYNE actuators cover an exceptionally broad range of motion and force control. The **Quasi-Hyper Series** requires solving inherent challenges from high-ratio reduction — limited backdrivability, restricted force sensing, and gearbox complexity. The **Hyper Series** requires solving challenges from the integrated elastic element — physically constrained control bandwidth, nonlinear and uncertain dynamics, and a fundamentally new approach to torque measurement. HYPERDYNE possesses a complete control-technology full-stack capable of solving every one of these challenges.

## Quasi-Hyper Series

Quasi-Hyper Series · CHALLENGE1

### Backdrivability Limitations

#### ◆ CAPABILITIES

The Q-Series, optimized for high power output, employs high-ratio reduction gearboxes — which inherently exhibit poor backdrivability. HYPERDYNE possesses dedicated technologies to enhance the intrinsic efficiency of the hardware itself.

#### ◆ WHAT WE DELIVER

- + Friction-compensation – based backdrivability enhancement
- + Inertia-compensation – based backdrivability enhancement

Quasi-Hyper Series · CHALLENGE2

### Force Sensing Limitations

#### ◆ CAPABILITIES

The Q-Series, optimized for high power output, does not include dedicated force-transmission sensing devices. Achieving sensorless estimation and control of output force is therefore essential.

#### ◆ WHAT WE DELIVER

- + Capability in designing diverse observers
- + Impedance control via sensorless estimation

Quasi-Hyper Series · CHALLENGE3

### Gearbox Complexity

#### ◆ CAPABILITIES

HYPERDYNE thoroughly understands and accurately models the inherent hardware characteristics of reduction gearboxes — including torque ripple and backlash — and provides effective compensation control technologies.

#### ◆ WHAT WE DELIVER

- + Compensation control for torque ripple and backlash
- + Modeling of complex gearbox characteristics

## Hyper Series

Hyper Series · CHALLENGE1

### Physical Bandwidth Limit Imposed by the Elastic Element

#### ◆ CAPABILITIES

Once an elastic element is introduced, the control bandwidth of the actuator becomes physically constrained. Through years of accumulated research, HYPERDYNE has developed a complete control-technology stack to overcome this fundamental limitation.

#### ◆ WHAT WE DELIVER

- + Precise force and impedance control based on detailed dynamic modeling
- + Universal applicability — from compact precision systems to high-load applications including vehicle suspension, steering, and robotic leg
- + Natural-dynamics control that leverages the energy-storage property of the elastic element as a performance asset

Hyper Series · CHALLENGE2

### Model Complexity & Uncertainty

#### ◆ CAPABILITIES

Elastic actuators are inherently complex modules. In addition to internal nonlinearities such as spring nonlinearity, gearbox ripple, motor cogging, inter-component friction, and axis-misalignment errors, uncertainties arising from interaction with the external environment must also be rigorously addressed.

#### ◆ WHAT WE DELIVER

- + High-precision analysis and control reflection of spring nonlinearities
- + Real-time compensation of gearbox ripple and motor cogging
- + Robust control under varying external load conditions

Hyper Series · CHALLENGE3

### Force/Torque Estimation Methodology

#### ◆ CAPABILITIES

Force sensors are expensive and vulnerable to mechanical shock. HYPERDYNE — leveraging its diverse elastic-element technologies — has developed methods to effectively estimate torque without sensors and apply it directly within the control loop.

#### ◆ WHAT WE DELIVER

- + Real-time estimation of external interaction torque without force sensors
- + Consistent external-torque frequency response across wide stiffness variations
- + Robust external-force estimation under high-impact and high-vibration environments
- + Ground reaction-force estimation for vehicle suspension/steering and quadruped robots

SECTION

# T3 System Application Technology

3 CATEGORIES · 6 ITEMS

A field-deployed industry – academia portfolio combining HYPERDYNE hardware (T1) with control and algorithms (T2). From vehicle chassis, suspension, and steering to walking platforms and actuator-based application modules.

**A Vehicle Chassis · Suspension · Steering Systems**

|     |                                          |    |
|-----|------------------------------------------|----|
| A-1 | Four-Wheel Independent Active Suspension | 12 |
| A-2 | Active Roll Stabilizer(ARS)              | 13 |
| A-3 | Next-Generation Linear Active Strut      | 14 |

**B Special-Environment & Locomotion Platforms**

|     |                                         |    |
|-----|-----------------------------------------|----|
| B-1 | Excavator Robot Platform                | 15 |
| B-2 | Five-Bar Linkage 2-DOF Hopping Platform | 16 |


**C Drive Module**

|   |                                            |    |
|---|--------------------------------------------|----|
| C | Integrated Drive and Steering Wheel Module | 17 |
|---|--------------------------------------------|----|



# T3-A-1 Four-Wheel Independent Active Suspension

## ACTIVE SUSPENSION SYSTEM



### Overview

A four-wheel independent active suspension system has been developed by applying high-load elastic actuators to each wheel of the vehicle. The system enables real-time control of force and impedance in response to road inputs. Through joint development with Hyundai Motor Company and Hyundai WIA, both HILS testing and prototype-level performance validation have been successfully completed.

### Features

- Configuration: elastic-actuator-based active suspension system
- Control: Skyhook and Groundhook control strategies
- Validation: HILS-based lifting experiments using a real corner module
- Joint development: Hyundai Motor Company and Hyundai WIA

### Advantages

- SEA-based high-torque, precision force control delivers active damping and stiffness beyond passive mechanical suspension
- Disturbance-observer-based robust control ensures stable behavior under irregular road disturbances
- Quarter-car-level HILS validation under vehicle-representative conditions – verified stiffness realization and damping-force effectiveness
- Real-time trade-off between ride comfort (damping) and handling (stiffness), adaptively optimized to driving conditions

## Applications

Premium passenger and SUV active suspension


Electrified platform (EV) underbody integrated suspension

Active damping for off-road and irregular-terrain vehicles

Ride-comfort optimization platform for autonomous vehicles

# T3-A-2 Active Roll Stabilizer (ARS)

## ANTI-ROLL BAR SYSTEM



### Overview

The Active Roll Stabilizer (ARS) is a self-balancing active roll control system that simultaneously improves driving stability and ride comfort by actively controlling vehicle body roll motion during cornering. A rotary series elastic actuator (SEA) drives the stabilizer bar, enabling continuous variation of roll stiffness according to driving conditions while achieving both high torque output and precise force control.

### Features

- Target control torque 1,000 Nm · step response within 200 ms · time constant ~30.5 ms
- Serial configuration: motor – three-stage planetary reducer – torsional elastic element – stabilizer bar
- Floating stator structure – actuator housing rotates together with left – right vehicle body motion
- Spring displacement/stiffness-based torque estimation + feedforward + feedback (FB-PD) force and impedance control

### Advantages

- High-torque precision force control up to 1,000 Nm based on rotary SEA elastic deformation (RMS error below 10%)
- Active suppression of vehicle body roll – maximizes cornering grip and steering stability while improving ride comfort
- Continuously variable roll stiffness and damping (impedance control) – supports both sport and comfort driving modes
- Low-pass filtering effect of elastic element absorbs external impacts – protects drivetrain and gearbox, improves durability

## Applications

Active Roll Stabilizer (ARS) and 48V chassis systems for passenger cars and SUVs


Premium suspension and cornering-stability control modules for EVs and hybrids

Off-road SUVs and pickup trucks requiring stabilizer decoupling

Active chassis control for ride comfort and driving safety in autonomous vehicles

# T3-A-3 Next-Generation Linear Active Strut

LINEAR ACTIVE STRUT



### Overview

The Next-Generation Linear Active Strut is an automotive active suspension actuator jointly developed with Hyundai Motor Company. To overcome the limitations of conventional hydraulic struts—oil leakage, bulky structure, and limited response performance—the system integrates a BLDC motor, ball screw, planetary reducer, and a series elastic actuator (SEA)-based linear drive module within a single strut cylinder as an electro-mechanical integrated architecture. With independent control at all four wheels, the system enables real-time regulation of vertical damping force and vehicle body motion, improving both ride comfort and driving performance simultaneously.

### Features

- Max thrust up to 6 kN · stroke speed > 1 m/s · target force rate 23 kN/s
- BLDC motor (Kt 0.11 Nm/A · 14 pole-pairs) + ball screw (lead 10–25 mm) + planetary reducer (ratio 4.5–7.5)
- F-SEA architecture: serial motor – screw – nut – elastic element – rod – integrated impact absorption and force sensing
- 150 A-class motor driver · linear displacement sensor · Damped Tester POC Verification Completed

### Advantages

- Faster response and more precise damping-force control vs hydraulic systems – target 23 kN/s force rate for 4 kN step input
- Encoder-based measurement of elastic deformation in F-SEA architecture – disturbance-robust precise force sensing and control
- DOB-based two-degree-of-freedom control combined with non-conductive liquid cooling – sustains stable continuous-operation performance

## Applications

Four-wheel active suspension for high-performance and premium passenger sedans


Active struts for ride-height adjustment and roll/pitch control in EVs and SUVs

Ride-comfort enhancement and precise body-attitude control for autonomous vehicles

Development platform for quarter-car HILS testing and active suspension control algorithms

# T3-B-1 Excavator Robot Platform

HIGH-LOAD · HIGH-PRECISION FORCE-CONTROLLED EXCAVATION ROBOT



## Overview

A next-generation electric excavation robot that integrates high-power series elastic actuators (SEA) into the boom, arm, and bucket axes. It simultaneously achieves ultra-precise force sensing at the 0.1 N level and high-output force up to 70 kN — capabilities unattainable with conventional hydraulic excavators — enabling human-level tactile interaction for defense EOD, demining, extreme-environment tasks (high vacuum, cryogenic), and autonomous excavation.

## Features

- Boom actuator — max thrust 73.3 kN · max speed 125 mm/s · motor power 24.5 kW · force-control bandwidth 5 Hz
- Arm actuator — max thrust 70.1 kN · max speed 155 mm/s · motor power 22.5 kW · force-control bandwidth 8 Hz
- Bucket actuator — max thrust 33.3 kN · max speed 195 mm/s · motor power 19.5 kW · force-control bandwidth 12 Hz

## Advantages

- Simultaneous realization of ton-level output (up to 73.3 kN) and ultra-precise force control at 0.1 N resolution
- Direct force estimation via elastic-deformation measurement — no additional load cells required
- Impact-absorbing elastic structure protects motor, gearbox, and control system under harsh operating conditions

## Applications

Defense and special equipment — demining, EOD, and explosive handling requiring precise contact control

Extreme-environment systems — high vacuum, cryogenic, and fine-dust environments (space exploration, lunar operations)

Construction and heavy-equipment automation — autonomous excavation based on precise contact and reaction-force control

Physical AI automation platforms — direct integration with autonomous-operation software via sensing-enabled actuator interfaces

# T3-B-2 Five-Bar Linkage 2-DOF Hopping Platform

## LEGGED LOCOMOTION PLATFORM



### Overview

A five-bar 2-DOF parallel platform driven by two base-mounted motors through serial and parallel links to a single end-point. Concentrating the actuators on the body side dramatically reduces the reflected inertia at the leg tip, enabling a legged-robot platform well suited to high-bandwidth force control and instantaneous impact response.

### Features

- Configuration: 2 base-mounted motors + 4-link, 5-bar closed-loop parallel mechanism (2-DOF end-point)
- Control space: joint / Cartesian / rotational workspace — triple representation supported
- Sensor-less ground reaction force estimation based on a Ground Contact Force Observer (GCFO)
- Validation: hopping experiments at 1,400 N/m virtual stiffness with force-plate-based ground-reaction measurement

### Advantages

- Actuators on the base minimize end-point reflected inertia — fast response and low impact transmission
- Parallel structure offers high stiffness and power density while keeping the links themselves lightweight — ideal for high-speed hopping and running
- Two-axis independent drive with bi-articular coordinate transform — intuitive force/position control in Cartesian (x, y) space
- Rotational-workspace-based GCFO enables real-time contact-force estimation without force/torque sensors

## Applications

Hopping/running leg modules for quadruped and biped robots (SLIP model)

Research platform for low-energy locomotion and hopping leveraging natural dynamics

Test rig for shock-absorbing landing control and landing-strategy optimization

Benchmark for sensor-less ground-reaction estimation and impedance-control algorithms

# T3-C Integrated Drive and Steering Wheel Module

## INTEGRATED DRIVE AND STEERING WHEEL MODULE



### Overview

A single wheel drive module integrating the traction and steering systems into one unit. Its steering axis rotates through 360°, allowing the driving force to be directed as required. Multiple modules can be combined to create an omnidirectional mobile platform capable of forward, backward, lateral, and diagonal travel, as well as in-place rotation. Its modular design enables flexible integration into mobile platforms of various sizes and purposes.

### Features

- Integrated wheel drive and steering system
- 360° steering for flexible travel direction control
- Independent drive and steering control for precise motion and orientation control
- Omnidirectional mobility through synchronized control of multiple modules
- Scalable mounting structure for integration into various mobile platforms

### Advantages

- Changes travel direction while maintaining the chassis orientation
- Excellent maneuverability in confined spaces through lateral movement and in-place rotation
- Precise position and orientation alignment with equipment and workstations
- Modular configuration adaptable to different platform sizes and payload requirements
- Simplified platform design and system integration through an integrated drive-and-steering structure

## Applications

Parts and material transport systems for smart factories

Four-wheel independently driven and steered omnidirectional mobile platforms

Transport platforms for warehouses and narrow aisles

Precision docking systems for production equipment, conveyors, and workstations

Mobile platforms equipped with robotic arms or inspection systems

R&D platforms for mobile robot motion and control technologies



SECTION

# T4 Evaluation & Benchmarking Infrastructure

4 ITEMS · DYNAMOMETER · 4-STEP PROTOCOL · QUARTER-CAR & HALF-CAR HILS · ROBOT HILS


Test and validation infrastructure that enables quantitative analysis of actuator dynamics and objective benchmarking.

Evaluation & Benchmarking Infrastructure


|   |                                                                |    |
|---|----------------------------------------------------------------|----|
| A | Dynamometer Test Infrastructure                                | 18 |
| B | Four-Stage Actuator Dynamic-Characteristic Evaluation Protocol | 19 |
| C | Quarter-Car/Half-Car HILS Tester                               | 20 |
| D | Robotic HILS Platform                                          | 21 |

# T4-A Dynamometer Test Infrastructure

## DYNAMOMETER TEST INFRASTRUCTURE



Single-axis Dynamometer



Dual-end Dynamometer

### Overview

A baseline setup that fixes the test actuator stator with a 3-jaw chuck and arranges an encoder, torque sensor, and AC servo motor in series on a single shaft. The self-centering 3-jaw chuck clamps actuators of various outer diameters without dedicated jigs, and the entire hardware is reconfigurable for different test conditions.

### Features

- Self-centering 3-jaw chuck — clamps actuators of various outer diameters without dedicated jigs
- No-load / fixed-load / external-load & excitation setups switched on a single hardware (no disassembly required)

### Advantages

- System identification, controller performance, and disturbance-response tests run on a single infrastructure
- AC servo motor switches between position / velocity / force control modes for static and variable load application

### Overview

A setup that mounts the test actuator directly on a central bracket with AC servo motors at both left and right ends. Independent control of the two motors enables bi-directional load and excitation, while a central in-line torque sensor and encoder simultaneously measure position and torque.

### Features

- Independent left/right AC servo motor control — simultaneous bi-directional load and excitation
- Test actuator mounted directly at center + in-line torque sensor & encoder for simultaneous position/torque measurement

### Advantages

- Enables bi-directional load and superposed excitation tests not reproducible on a single-axis setup
- Time- and frequency-domain standard excitation profiles (Step / Ramp / Chirp / PRBS) for direct cross-model comparison

## Applications

Dynamic-characteristic evaluation of cobot and humanoid joint actuators

Quantitative back-drivability and transparency assessment

Active-suspension actuator test & evaluation


Dynamic-characteristic benchmarking of commercial and new actuators

# T4-B 4-Step Actuator Dynamic-Characterization Protocol

## 4-STEP EVALUATION PROTOCOL

### 1. System Identification


Quantification of Mechanical Characteristics



- Inertia, Friction, Backlash, Stribeck

### 2. Control Performance Evaluation


Ensuring Tracking Performance



- Position/Velocity/Force Tracking, Bandwidth, Damping Ratio

### 3. Load Robustness Evaluation


Robust Tracking under Variable Load Conditions



- Performance Evaluation under Variable Load Conditions

### 4. Disturbance Rejection Evaluation

Quantification of Regulation Capability under Disturbances



- Performance Evaluation of Disturbance Rejection

## Overview

A four-step evaluation protocol established to systematically reveal the dynamic performance of actuators that static catalog specs cannot capture. The protocol proceeds in order: ① system identification, ② control performance under non-ideal conditions, ③ static and variable load robustness, ④ dynamic disturbance / back-drivability interaction — yielding both time- and frequency-domain metrics at every step for objective cross-actuator comparison.

## Features

- Step 1 — System identification: friction, backlash, inertia, and other base parameters
- Step 2 — Control performance: response speed, steady-state error, vibration suppression
- Step 3 — Load robustness: static and variable load disturbance handling
- Step 4 — Interaction: chirp-based dynamic disturbance and back-drivability assessment

## Advantages

- Provides identical-condition test scenarios that enable 1-to-1 comparison between actuators
- Integrated evaluation of position / velocity / force control performance and interaction performance
- Quantifies key humanoid / cobot metrics such as back-drivability
- Real-time validation system grounded in measured data

## Applications

Dynamic benchmarking of commercial and new actuators


Comparative analysis across QDD / SEA / harmonic-reducer types

Actuator selection process for robot manufacturers


Performance validation for actuator control-algorithm R&D

# T4-C Quarter-Car / Half-Car HILS TESTER

## QUARTER-CAR / HALF-CAR HILS TESTER



Quarter-Car HILS Tester



Half-Car HILS Tester

### Overview

A HILS tester that mounts a real suspension on a quarter-car frame replicating one quarter of a vehicle, and reproduces road inputs through a linear-motor shaker. It validates damping and stiffness control algorithms of active suspensions (active struts, semi-active dampers, etc.) at the physical-prototype level before vehicle integration.

### Features

- Quarter-car frame + real suspension strut mounted
- Direct linear-motor drive — reproduces structured/unstructured road profiles (ISO 8608, etc.)
- MacPherson / double-wishbone compatible — adjustable links and mounts cover multiple vehicle geometries
- Electric-winch sprung-mass loading — 50 kg load step combinations, single-operator usable
- Mechanical gravity-compensation springs — no dynamic interference, zero maintenance
- In-house motion controller + model-based advanced control (feedforward + feedback + iterative learning)

### Advantages

- Validates the stability and performance of suspension control algorithms at the physical level prior to vehicle integration
- Reproduces a wide range of scenarios from ISO 8608 road profiles to actual driving-data replay
- Immediate SW customization — adding test modes, modifying control logic, and other on-site requests handled directly
- Fully domestic system — no lead time on parts, service, or technical support

### Overview

A half-car (1/2 vehicle) HILS tester that simultaneously simulates the left and right wheels, validating active roll-control algorithms (ARS, Active Roll Stabilization) — including roll-direction behavior — at the physical-prototype level. It experimentally evaluates left-right wheel coupling, roll stiffness, and anti-roll-bar effects that quarter-car rigs cannot reproduce.

### Features

- Two independent left/right linear-motor shakers — in-phase (heave) and anti-phase (roll) excitation
- Half-car frame with real left/right suspensions and an anti-roll bar (stabilizer) mounted
- Integrated testing of active anti-roll bars (ARS), semi-active dampers, CDC, and other roll-control devices
- Same adjustable link/mount structure as the quarter-car rig — covers different track widths and suspension geometries
- Independent left/right sprung-mass loading — reproduces asymmetric (offset) loading conditions

### Advantages

- Direct measurement of lateral dynamics — roll natural frequency, roll damping ratio, roll stiffness — at the physical level
- Reproduces cornering load-transfer scenarios — quantitatively evaluates anti-roll-bar and ARS control performance
- Simultaneous left-right excitation enables separation of heave and roll modes
- Shares control SW and motion-controller platform with the quarter-car tester — unified operation, minimized learning cost

## Applications

Validation of vehicle active-suspension control algorithms


Performance and durability evaluation of Linear Active Struts (LAS)

Zero-Force Control · Impedance Control Logic Demonstration

Next-Generation Electro-Hydraulic Integrated Damper  
Verification Platform

# T4-D Robotic HILS Platform

## ROBOTIC HILS PLATFORM



### Overview

A universal Hardware-in-the-Loop Simulation (HILS) platform that enables joint-level validation of robots with arbitrary morphologies — quadrupeds, manipulators, humanoids, and other systems — without requiring a fully built physical robot. The simulation calculates the joint loads generated by the robot's geometry and motion, a dynamometer array reproduces these loads in real time, and the measured responses of the actual actuators are fed back into the simulation. This lets actuator and controller validation — traditionally possible only after completing the full robot — begin from the early design stage, and extends to a Design-in-the-HILS-loop framework where parameters such as motor specs, gear ratios, link lengths, inertia, and stiffness are automatically explored and optimized within the HILS environment.

### Features

- N-axis dynamometer array, scalable according to robot morphology
- Real-time loop of 1 ms, 1 kHz, with EtherCAT-synchronized control
- Customizable simulation environment including terrain, gravity, contact conditions, and external disturbances

### Advantages

- Enables integrated validation of actuators and controllers before physical robot fabrication, significantly reducing design-modification cost and development time
- Applicable regardless of robot type — quadrupeds, bipeds, manipulators, humanoids — allowing multi-robot R&D on the same infrastructure
- Allows flexible modification of virtual robot geometry, environments, and disturbance conditions — flat ground, slopes, space, and disaster environments
- Supports automatic exploration and optimization of design parameters such as link length, reduction ratio, inertia, and stiffness within the HILS loop

### Applications

Pre-validation of actuators for arbitrary robot morphologies, including quadrupeds, bipeds, manipulators, and humanoids

Validation of control algorithms and RL policies before deployment to physical robots, plus sim-to-real data acquisition

Optimization of motor, reducer, and link design parameters through an automated Design-of-Experiments loop

Digital-twin-based virtual R&D platform and preliminary evaluation of new robot concepts

THANK YOU

# PHYSICAL INTELLIGENCE

WEB

[hyperdyne.co.kr](http://hyperdyne.co.kr)

EMAIL

[ceo@hyperdyne.co.kr](mailto:ceo@hyperdyne.co.kr)

TECH INQUIRIES

High-power Actuators · Control & Algorithms · System Applications · Evaluation & Benchmarking